



# ALC Sentinel

4 channel class-D amplified  
loudspeaker controller

user's manual

Featured models:

Sentinel 3

Sentinel 10



evolutionary audio solutions™

# Table of contents

1	<b>Introduction</b>	3
2	<b>Important safety instructions</b>	6
3	<b>Precautions</b>	7
4	<b>Installation</b>	8
5	<b>Overview</b>	11
6	<b>Connections</b>	14
7	<b>Operation</b>	17
	7.1 Tab section Overview	19
	7.2 Tab section Gain	21
	7.3 Tab section Eq	23
	7.4 Tab section Delay	25
	7.5 Tab section Presets	26
	7.6 Tab section Routing	28
	7.7 Tab section System	29
	7.7.1 Speaker	29
	7.7.2 Amp	29
	7.7.3 Setup	30
	7.7.4 Lock system	30
	7.7.5 Lock preset	30
	7.7.6 High headroom/ low noise	31
	7.7.7 Mute preferences	31
	7.7.8 Backlight brightness	31
	7.7.9 Screen saver	31
	7.7.10 Change date/ time	31
	7.7.11 Olog	32
	7.7.12 Clean olog	32
	7.7.13 Copy log files	32
	7.7.14 Firmware	32
	7.7.15 Project	33
	7.7.16 Network	33
	7.8 Remote control through a VNC client	34
	7.8.1 Remote control with the Virtual Encoder™	35
8	<b>Safety</b>	36
9	<b>Service and support</b>	37
10	<b>Specifications</b>	40
11	<b>Block diagram</b>	42
12	<b>Block diagram Bridge mode – ALC Sentinel 3 only</b>	43
13	<b>CE declaration of conformity</b>	44



# 1. Introduction

---

Dear customer,

Congratulations on your purchase of an Alcons Audio ALC Sentinel amplified loudspeaker controller, and thank you for your confidence in Alcons products. We are very honoured to welcome you to the growing family of Alcons ambassadors!

For your safety, please read the Important safety instructions and the Precautions section before installing and operating the amplifier.

The “engine” behind every Alcons sound system is the Amplified Loudspeaker Controller. The ALC is a combination of a loudspeaker controller and a very high efficiency power amplifier. The Sentinel range sets new standards in sound quality, by bringing Alcons famous pro-ribbon sound into the digital amplification domain, while increasing system performance to the highest levels.

The ALC Sentinel is proprietary designed and developed by Alcons Audio and features a powerful 4-channel DSP-based controller with patented Class-D amplifier stages onboard.

Main focus in the development of the Sentinel range was to obtain a very low distortion “audiophile-grade” signal drive and a surplus of headroom under any circumstance, to get the absolute maximum performance out of the Alcons sound systems.

Speakon® and PowerCon® are trademarks of Neutrik® AG.

## ALC Sentinel features

### Fully-intuitive control and feedback

The Sentinel features on-unit control over the complete amplifier and processor sections through a 4.3” (480 x 272 pixels) touch screen TFT-LCD display and a multi-colour LED-illuminated rotary encoder. A dedicated micro-computer “oversees” and controls all processes; Through the internal I<sup>2</sup>C communication network, all parameters of DSP, amplifier stages, power-supplies and micro-controllers can be monitored and guided, for maximum operating efficiency and full status/application logging.

### Compact and light weight

The combination of Class-D designed amplifier stages, switch-mode power supplies and specific focus on a weight and space-saving structure, brings a highly efficient power-to-size/weight ratio.



# 1. Introduction

---

## 4 x 4 Input / Output matrix

With 4 individual inputs, a free-configurable input / output matrix is formed. Each channel offers a choice of up to 4 inputs, incl. input-summing, with selectable analogue or digital (AES3) input signals.

## Audiophile signal processing

The internal D/A conversion accepts signals of up to 192kHz, with other sample rates from 44.1 kHz being automatically up-/down-sampled to 96kHz processing. In striving for the highest audio quality possible, a fully customized sample rate conversion is implemented. This enables true high-end HiFi sound quality at concert SPL's.

## Powerful Drive Processing

The speaker- and signal processing is taken care of by a 450MHz Analog Devices SHARC™ processor (S3: 400MHz). This is one of the most powerful DSP engines available and enables fastest processing of even the most complex (IIR, FIR) algorithms for protection, filtering, power and response optimisation . On-board features include 6-band parametric/shelf/pass-filter eq. per channel, delay, factory presets for all systems and system configurations.

## SIS Signal Integrity Sensing™

SIS is a unique feature installed in all Alcons amplifiers that dynamically senses the signals arriving at the loudspeaker terminals, and so compensating for errors introduced by cable resistance and self-induction. Doing so, SIS™ reduces linear and non-linear distortion, compensates signal loss and maintains high damping figures, thus achieving high signal integrity, regardless of the cable length.

## Intelligent power-supply

The power-supply section is controlled by the Power Detection Circuit, that measures the input AC current and protects against high-voltage overload up to 400V. It also features automatic selecting of the correct operating AC current circuit 115V / 230V ("global power supply"). It also features a "redundant setup" with load balancing capabilities. when one SMPS is down, other SMPS automatically takes over for all 4 amp.channels.



# 1. Introduction

---

## **Bridged mono mode - ALC Sentinel 3 only**

Bridged mono mode combines the output power of two amplifier channels into one loudspeaker load, resulting in twice the voltage swing and four times the power in a specific load. *See the Connections section!*

## **Easy servicing and upgrading**

The modular design of the complete ALC, caters for easy “in-the-field” servicing and upgrading; The power supplies and amp.stages can be individually exchanged in case of emergency, significantly reducing down-time. The DSP is mounted on a separate PCB, thus can be easily “future-proof” upgraded when required.

The Sentinel3 and Sentinel10 share the same front control panel; When exchanging during servicing, the front control panel automatically detects what model it needs to control; A Sentinel3 or Sentinel10. This saves inventory and guarantees a fast turn-around repair.

## **Remote-control / Networked audio**

The Sentinels are prepared for ALControl™; Alcons Audio’s proprietary, Ethernet-based ALC network . ALControl™ can control individual or clusters of Sentinels, with functions like grouped eq’ing, event and (on-line) system monitoring and repairs, firmware uploads, a.o. Through two additional RJ45 connectors (redundant) and optional network modules, the Sentinel is prepared for different audio-over-network standards.

## **Maximum operating reliability**

The Sentinels feature most advanced protection circuitries for optimal reliability; Amplifier stage protection against DC, subsonic, RF, short circuit for both speaker signal and sensing signal as well as over-/under voltage; SMPS supplies are protected against over-/under AC voltage. These circuits cut-off operation, when detected.

The dynamic current, voltage and power limiting as well as thermal protection circuits modulate the signal down to safe levels; Together with the redundant-switching between the two SMPS supplies, these modulating safety circuits maintain operation under the most difficult situations.



## 2. Important safety instructions

---

**Warning:** – To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture.

1. Read these instructions.
2. Keep these instructions.
3. Heed all warnings.
4. Follow all instructions.
5. Do not use this apparatus near water.
6. Clean only with dry cloth.
7. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
8. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus that produce heat.
9. Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
10. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus
11. Only use attachments/accessories specified by the manufacturer.
12. Use only with the cart, stand, tripod, bracket or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.
13. Unplug this apparatus during lightning storms or when unused for long periods of time.
14. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as, the power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.



The lightning flash with arrowhead symbol within a triangle, is intended to alert the user to the presence of uninsulated dangerous voltage within the enclosure that may be a risk of electric shock to humans.



The exclamation point within a triangle is intended to alert the user to the presence of important operating instructions in the literature accompanying the product.



# 3. Precautions

---

**Save the packing material.** Should you ever need to ship the amplifier, use only the original packing.

**Read this manual carefully before installing and operating your amplifier.** Retain this documentation for future reference.

**Always operate the amplifier with a grounded AC mains supply.** Ensure that the quality of the mains supply is good enough and that it can supply the required peak currents. In addition, proper earthing is necessary to prevent hum and safety problems.

**Do not use the amplifier if there is visual damage to the enclosure or cables.** Inspect the amplifier and wiring before use. When in doubt, have the amplifier inspected by authorized technical personnel.

**Do not make connections to the amplifier while it is switched on.** Always shut off the amplifier when making connections to it, and mute the inputs when making connections to preceding equipment in the chain.

**Do not spill water or any other liquid to or into the amplifier.** Do not operate the amplifier if suspected or standing in liquid. Do not use liquid or aerosol cleaners. Clean only with dry cloth. Leave the amplifier switched-on overnight during multi-day outdoor events, due to night-time air moisture differences. Ensure proper weather protection

**Do not block the air intake for the fans on the rear, or the exhaust ports on the front side of the amplifier.** The amplifier can run hot, or even go into protect mode if there is insufficient cooling air.

**Do not operate the product near any heat source, such as radiators or other devices or expose to direct sunlight.** This will affect the temperature headroom.

**Make sure that possible dust filters are cleaned frequently.** Dirty filters can easily block the flow of air.

**Do not remove the cover.** There are no user serviceable parts inside the amplifier. Removing the cover exposes you to dangerous voltages inside the amplifier.

**Refer servicing to qualified service personnel.** Servicing is required when the amplifier has been damaged in any way, liquid has been spilled on or into the amplifier, does not operate normally or has been dropped.

**Do not series or parallel connect an amplifier output with any other amplifier output.** Connecting outputs together can cause damage to the amplifiers.

**Use the mains plug as the disconnecting device.** keep it readily accessible. If the mains plug is not readily accessible due to mounting in a 19" rack, then the mains plug for the entire rack must be readily accessible.




## 4. Installation

---

### Unpacking

Carefully open the shipping carton and inspect the amplifier. Every Alcons amplifier is thoroughly tested and inspected before leaving the factory and should arrive in perfect condition. If you find any damage, notify the shipping company immediately. Only you, the consignee, may initiate a claim for shipping damage. Be sure to save all packing materials for the carrier's inspection.


Please save the packing material. If you ever need to ship the amplifier back to your dealer or the factory, you should only use the original packing.



## 4. Installation

### Sentinel parts and dimensions

- 1) Finger guard cooling fans
- 2) SRMB rear rack mounting set
- 3) Rack handle



### **Mounting**

The ALC Sentinel amplifiers mount in standard 19-inch racks. A rear mounting set gives additional support. Rear support is highly recommended in all applications, especially with mobile and touring systems. ALC Sentinels can be stacked directly on top of each other. There is no need for spacing between units. Ensure that the bottom ALC Sentinel has a bottom support over the entire depth.



## 4. Installation

---

### Cooling and ventilation

The ALC Sentinel amplifier uses forced air cooling in order to maintain a low operating temperature. In this device the cooling air enters at the back and the hot air leaves the amplifier at front side. Make sure that there is an adequate supply of fresh, cool air at the back of the amplifier, and that there is sufficient space in the rack for the exhaust air to escape.

Due to the small diameter fans and high turning speed, high noise levels can be encountered.

**Do not use ALC 2/ 4 /6 amplifiers (front to side cooling) with Sentinel 3 or 10 amplifiers (rear to front cooling) in one rack.**

### Mains Power

The AC mains voltage for the ALC Sentinel amplifier is stated at the rear of the amplifier near the PowerCon® input.

Your local power will be detected automatically. For safety reasons you must also ensure that the AC supply is properly grounded. The AC current draw is measured according to the IEC 65 safety standard. The normal operating power is measured using pink noise, with an average power equal to 1/8 of full power. This corresponds to normal music being played to the clip level of the amplifier. The table below shows the AC current draw for different loudspeaker loads.

Make sure your AC power distribution can handle the currents demanded by the amplifiers.

The AC mains power may not deviate more than +/-10% from the nominal values.



**Operate the amplifier at a high-range supply (208 to 240 V), if possible.**


**Only use two (2) Sentinel 3 or one (1) Sentinel 10 per 16A mains outlet for optimal performance. It is possible to use multiple ALC Sentinel 3 or 10 amplified loudspeaker controllers in “low power” applications. Due to the high inrush current, it is advised to switch on a maximum of two units at the same time.**

Sentinel 3	Peak output power/channel	1/8 <sup>th</sup> output power(-9dB):	BTU / W
8 Ω	400 W	536 W	1224 / 359
4 Ω	750 W	788 W	1494 / 438

Sentinel 10	Peak output power/channel	1/8 <sup>th</sup> output power(-9dB):	BTU / W
8 Ω	1250 W	1328 W	2244 / 658
4 Ω	2500 W	2057 W	3015 / 884

## 5. Overview

---



### Front panel


- |                  |   |
|------------------|---|
| 1) Mounting ears | 19" rack mounting                             |
| 2) USB port      | USB Host A port – for all USB storage devices |
| 3) TFT Display   | Full Colour display with touch screen*        |
| 4) Encoder       | Multi Colour Encoder                          |
| 5) Rack handle   | Use both handles for manual transportation    |

\* The touch screen incorporates a thin flexible sheet that may be damaged by sharp objects or heavy treatment.



# 5. Overview

## Rear panel



## 5. Overview

---

- 1) **Finger guard**            The finger guard protects the fan intake. Do not block this area, because this will reduce the airflow.
- 2) **Networked Audio Inputs 2,1** Connect two RJ-45 connectors and leads for the networked audio inputs. One lead is for redundancy.
- 3) **AES/ EBU\* inputs 2,1** Connect your AES/ EBU signal source for channel 1 and 2 to the female XLR connector input 1 and connect your AES/ EBU signal source for channel 3 and 4 to the female XLR connector input 2.
- 4) **AES/ EBU\*\* link 2,1** These XLR connectors are internally hardwired to the AES/ EBU input connectors. You can use one of these male connectors to 'daisy chain' channel 1, 2 or 3, 4 input signal to the next amplifier.
- 5) **Analog Input 4,3,2,1** Connect your signal source for channel 1,2,3 or 4 to one of the female XLR connectors.
- 6) **AC power input**        Connect the supplied AC mains cable to this connector. Make sure your mains supply matches the specifications stated on the label next to this connector.
- 7) **Outputs 4,3,2,1**        Four 4-pole Speakon® connectors are installed to connect your loudspeakers to the amplifier channel 1,2,3 and 4.
- 8) **ALControl™**            Connect a RJ-45 connector and lead for the ALControl™ communication. See the ALControl™ manual for further instructions.

\*AES/EBU is a standard used for the transport of digital audio signals between professional audio devices, as described in IEC 60958 and AES3. The AES3 and analogue inputs are calibrated according to EBU standard (-18dBFS = 0dBu). The AES3-link connection is actively buffered by the Sample Rate Converter, so no external buffering is required. Thus the AES3-link is active when the unit is switched on.


\*\* AES/EBU can be daisy chained up to 4 amplifiers max.

## 6. Connections

---

### Inputs

The ALC Sentinel has female XLR connectors for the signal inputs and male XLR connectors for the input links. These connectors are wired with pin 2 'hot'.



The link connectors can be used to daisy chain the (digital) input signals to another amplifier. If you want to drive the amplifier from an unbalanced source, preferably connect pin 3 to pin 1 in the source connector. If this is not possible, connect pin 3 to pin 1 at the amplifier's connector. Remember, that balanced connections are less susceptible to AC hum, however unbalanced signals can be used for short cable runs.

### Outputs


Loudspeakers are connected using Speakon® connectors. For each channel a Speakon® connector is available. Due to the SIS (Signal Integrity Sensing™) feature on the ALC Sentinel, there are four connections per channel instead of two. The two extra wires are used for voltage sensing at the loudspeaker terminals. The output+ and sense+ wires are connected together at the loudspeaker+ terminal, and the output- and sense- wires are connected together at the loudspeaker- terminal. All Alcons loudspeaker cabinets are SIS pre-wired. If your loudspeakers are not prepared for SIS wiring you can connect the sense wires to the output wires at the loudspeaker input. If you do not want to use the SIS feature at all, the sense wires should be connected to the output wires at the amplifier output in the Speakon® connector.

#### **WARNING!**

Never connect the sense+ to the output- terminal or vice versa, or short circuit both sense wires! Since you are disabling the amplifier's feedback network, the amplifier can produce a large amount of DC at its output. Through its protection circuitry, the Sentinel will shut-off and will not pass any audio.


# 6. Connections

The Speakon® connector is wired as follows:




Speakon® male plug viewed from the wiring side


- 1+ Output+
- 1- Output -
- 2+ Sense +
- 2- Sense -



Use bridge mode when you want to combine the power of amplifier channel 1+2 or 3+4 into one loudspeaker load. In bridge mode connect your loudspeaker with or without SIS to the channel 1 and channel 2 outputs (or channel 3 and 4) as shown above. Sentinel 3 only!



Normal loudspeaker operation



Loudspeaker connection without SIS™



## 6. Connections

---

For a given loudspeaker impedance, the proportional power loss as a function of cable length and cable gauge is given in the next table:

	8 Ω				4 Ω			
	1.5 mm <sup>2</sup>	2.5 mm <sup>2</sup>	4 mm <sup>2</sup>	6 mm <sup>2</sup>	1.5 mm <sup>2</sup>	2.5 mm <sup>2</sup>	4 mm <sup>2</sup>	6 mm <sup>2</sup>
5 meters	1.4 %	0.8 %	0.5 %	0.4 %	2.8 %	1.7 %	1.1 %	0.7 %
10 meters	2.8 %	1.7 %	1.1 %	0.7 %	5.4 %	3.3 %	2.1 %	1.4 %
15 meters	4.1 %	2.5 %	1.6 %	1.1 %	7.8 %	4.9 %	3.1 %	2.1 %
20 meters	5.4 %	3.3 %	2.1 %	1.4 %	10.2 %	6.4 %	4.1 %	2.8 %
25 meters	6.6 %	4.1 %	2.6 %	1.7 %	12.4 %	7.8 %	5.0 %	3.4 %
30 meters	7.8 %	4.9 %	3.1 %	2.1 %	14.5 %	9.3 %	6.0 %	4.1 %
40 meters	10.2 %	6.4 %	4.1 %	2.8 %	18.5 %	12.0 %	7.8 %	5.4 %
50 meters	12.4 %	7.8 %	5.0 %	3.4 %	22.1 %	14.5 %	9.6 %	6.6 %

To calculate the SPL losses from these percentages in dB's, the following equation may be used:

$$\text{dB loss} = 20 * \log(1 - (\% \text{loss}/100))$$

In the next table a few percentages are converted to dBs:

% loss	dB loss
1 %	0.1 dB
2 %	0.2 dB
5 %	0.4 dB
10 %	0.9 dB
15 %	1.4 dB
20 %	1.9 dB
25 %	2.5 dB
30 %	3.1 dB
35 %	3.7 dB

# 7. Operation

---

## Power On/Off

The mains AC power of the amplifier is switched on when the PowerCon is connected.



***Each setting is automatically stored in memory, 30 seconds after the last user change. It is advised, to switch the amplifier off only, 30 seconds after the last instruction / setting change (otherwise the setting change will not be stored); it is also possible to double-click the encoder, with which the settings are manually stored.***



***Using AES signal in daisy chain - When one of the interlinked amplifiers is switched off, the following amplifier will not receive the AES signal. The reason for this, is that the AES signal is actively buffered.***



***Panic Mute - By pressing the illuminated rotary encoder for 2 seconds, all channels will be switched into mute. To un-mute, go to the Overview Tab or Gain Tab screen. This feature can be disabled in the Mute preferences menu.***



***Stand-by mode - By pressing the rotary encoder for 4 seconds, the amplifier can be put in Stand-by mode through the pop-up on/off selection menu: In Stand-by mode the power supplies and amplifier stages are switched on/off, and display is dimmed to 10%. Another way of switching on/off, is through the PowerCON connector on the rear of the amplifier; This way, every function (also the front) is switched off.***

# 7. Operation

## Multi-colour LED encoder




Fig 1

Fig 2

Fig 3

Fig 4

The rotary encoder features a Multi-colour LED, which shows the status of the amplifier..

White (fig.1)

White blinking

### **Normal operation**

**Eq settings changed** - with changing settings in the equaliser-section, the encoder will blink, indicating that changes have been made to the stored settings.

Blue (fig.2)

Green (fig.3)

**Initialisation** - DSP is being synchronised with the front UserInterface (only during amplifier start-up phase).

**Save eq settings** - after pressing the white-blinking encoder, the new setting is confirmed by a short, green-blinking encoder (only in the Eq menu).

Red blinking (fig.4)

**Error detected** - what causes the error notification, can be checked in the “oplog” (“system” -> “oplog”).



***In an error situation (red-blinking encoder), it is not possible to see if changes are made in the eq-settings (white-blinking encoder) nor if they are being stored (short green-blinking encoder -> white encoder) as the error condition overrules this.***



***For service purposes, a log file can be downloaded from the controller-amplifier, through the USB port. See procedure in Tab section system/ copy log files.***

# 7. Operation

---

## Touch screen menu

The touch screen function is applied for (de-)activating of a selection on the menu screen. Through the rotary encoder a specific value can be set (turn) and can be confirmed (click).

The menu is divided in different “Tab sections” under which a function-dedicated page is located.

***This guide relates to Sentinel amplified loudspeaker controllers with front firmware v1.3***

### 7.1 Tab section: Overview

In this section, an overview is given of the most important settings, as they have been selected.

Adjustments of these settings are limited to enable/disable in this section. Value changes of these parameters can be made in each specific function Tab section. Furthermore, the status of signals (green = input signal present, yellow = input signal 0dB, red = output signal clip) and of the amplifier stages temperature (blue = ok, orange blinking = channel close to thermal shut down) is displayed.

**Gain** - can be activated or de-activated (“gain muted”): Specific values can be entered in the “Gain” section.

**Eq** - can be activated or de-activated: Specific values can be entered in the “Eq” section.

**Delay** - can be activated or de-activated: Specific values can be entered in the “Delay” section.

**Preset** - shows the name of the selected factory system preset: Systems can be selected in the “Presets” section.

**Routing** – Shows the routing of the audio signal.

**System** – System parameters can be read or set, that are not required for “daily” operational usage.

**Name** - shows the customized name that each channel can be given. Pressing this field, activates a qwerty keyboard pop-up, with which the name can be entered (after clicking away the keyboard, one lands in the “Preset” tab section).

Input shows “analog” or “digital”, for the selected input; Also the input channel number is shown (1, 2, 3, 4). Specific values can be entered in the “Routing” section.

# 7. Operation

## 7.1 Tab section: Overview



Fig 5. All channels no signal present, gain muted, amplifier temperature normal



Fig 6. All channels signal present



Fig 7. Output signal clip channel 1, signal -16,5dB channel 2-4

# 7. Operation

---

## 7.2 Tab section: Gain

In this section, the gain settings for each of the 4 channels can be entered; Via this Gain Tab section, or the Overview Tab section, this function can be “enabled”/”disabled” (muted) per channel.

Each channel can be muted individually or in cluster; Subsequent channels can be linked, with which these channels follow the same gain setting, as the initial channel has been set (so channel 3 and 4 linked with channel 2, values are set with just channel 2).



***The Sentinel features “Panic Mute”: By pressing the illuminated rotary encoder for 2 seconds, all channels are switched into mute. To un-mute the channels, go to the Overview section or Gain section screen. Panic Mute can be switched on/ off in the mute preferences menu through the system tab.***

The gain value can be entered between -60dB up to +6dB, in steps of 0,5dB.

The bar-graph indicators located left from the Mute/Gain/Link controls, are the input (left) and output (right) VU-meters. The scales run from bottom to top; The solid bar shows the average signal, the tops show the peak signal; The indicators are green until 0dB, above 0dB they turn from yellow to dark orange. The separate clip indicators blink red and are located above the bar graphs.

The input indicator is located before the gain control, so this functions as “input signal present” indication.

The third bar-graph indicator shows the “Guidance” (gain-reduction): This is the limiting of the amplifier output for the protection of the connected speaker (this can be excursion or RMS limiting); As such, this works different for each speaker/preset. The scale runs from top to bottom, colors yellow to dark orange; When the bar reaches the bottom, maximum compression/limiting is reached. It is not a problem when the gain reduction is activated, but the LF response and overall dynamics will be reduced.

# 7. Operation

## 7.2 Tab section: Gain




Fig 8. Output channels 3 and 4 muted




Fig 9. Guidance on all channels




Fig 10. Output gain clip on channel 1



# 7. Operation

## 7.3 Tab section: Eq

In this section, the equalizing settings for each of the 4 channels can be entered; Via this Eq Tab section, or the Overview Tab section this function can be “enabled”/ ”disabled” (bypass) per channel.


Per channel there are 6 free-configurable equalizing bands available: Controllable parameters are frequency (f), q-factor (Q) and gain (g).

Every band can be functionally changed from parametric equalizing to low-pass, high-pass, low-shelf or high-shelf filtering. In addition, each band can be by-passed or switched-off individually.

Each parameter can be set to fine or coarse. (“fine” shown on picture).

With the “rst.” button, all Eq parameters can be reset on the current channel.

Use the “phase change” button (red is activated) to reverse the phase. Please be aware that this stays activated when the Eq is disabled



***When switching-off the band, the values are re-set to factory default!***

Each band can also be by-passed, while keeping the settings, by touching the band button. To re-activate the band again, the band button needs to be touched another time.

Each band has its own color in the display graph; The color of the active band that's being set lights up. The total summed equalizing of that channel (up to 6 bands) is being indicated by a white line.

Subsequent channels can also be linked, with which these channels follow the same eq settings, as the initial channel has been set.

For example channel 3 and 4 linked with channel 2, values are set with just channel 2.



***Changed settings in the eq section need to be confirmed/saved by pressing the rotary encoder.***

# 7. Operation

## 7.3 Tab section: Eq



Fig 11. Equalizer section channel 1, band 1 parametric EQ enabled and active




Fig 12. Equalizer section channel 1, band 2 enabled and bypassed



Fig 13. Equalizer section channel 1, disabled




Fig 14. Equalizer type selection .

# 7. Operation

## 7.4 Tab section: Delay

In this section, the delay settings for each of the 4 channels can be entered; Via this Delay Tab section, or the Overview Tab section this function can be “enabled”/”disabled” per channel.

The delay function can be set to “absolute”, with which delay values are set as actual absolute values, including the latency of the Sentinel (used when Sentinels are mixed with other amplifiers/delay devices). Delay set to “relative” sets the delay values, excluding the latency of the Sentinel (used when solely Sentinels are deployed).



**From firmware v1.36 or higher, a DDP-equipped ALC needs 1,875 ms latency, to match a Sentinel amplifier.**

Per channel, the delay values can be entered in meters (mtr), feet (ft) and milli-seconds (ms) to a maximum of 99,9meters, 327.67ft and 341,42ms. The step size can also be adjusted: per encoder click 0,15meters, 0.5ft, or 0,52ms (“coarse”) and 0,01meters, 0.01ft or 0,01ms (“fine”). Subsequent channels can also be linked, with which these channels follow the same eq settings, as the initial channel has been set. For example channel 3 and 4 linked with channel 2, values are set with just channel 2.



Fig 15. Delay tab, all channels enabled, delay “relative”

# 7. Operation

---

## 7.5 Tab section: Presets

In this section, the system presets for each of the 4 channels can be selected; All available system presets can be called and selected through the rotary encoder.

Each channel can be assigned a different system preset; This can be an Alcons system, but it is also possible to use the amplified loudspeaker controller as a “non-Alcons-specific” linear amplifier, through the “LINEAR” preset. Herewith, no system processing is activated, but all other processing functions (equaliser, delay, routing, gain) remain active.

When a system features a bi-amp or multi-amp configuration (requiring 2 or more amplifier channels, i.e. LR16, LR24, BC543), then at selecting the preset, automatically the consecutive channel/s is/are reserved for the 2nd (3rd + 4th) channel of the selected system. These additional channels (“Slave”) are not individually controllable, but follow the settings of the 1st set channel (“Master”).

For example when preset “LR24” is being selected (4 channels required) on channel 2, a message pops-up “not enough channels free for this preset” and the selection is refused. The preset key will show “empty”; No preset is set and the amplifier will not pass any audio.



Fig 16. Preset tab, channel 1 to 4 factory preset selected

# 7. Operation

## 7.5 Tab section: Presets




Fig 17. Scroll bar for selecting the different system presets




Fig 18. Bi-amp preset channel 1 disabling active control channel 2

# 7. Operation

## 7.6 Tab section: Routing

In this section, the routing for each of the 4 channels can be selected; Through the 4x4 matrix, per channel (4) a choice is available of available inputs (4). Up to 4 inputs can be selected per channel (i.e. mixed-mono signal for subwoofers). In addition, analogue or digital (AES3) input signal can be selected (w. digital inputs, sample rate is automatically up/down sampled to 96kHz internal frequency).

The Sentinel3 (menu as shown below) also offers the choice of operating the amplifier channels in bridge-mode (1+2, 3+4). The bridge-mode option is not available on the Sentinel10 (and as such not visible on the menu/display).



**For using the amplifier stages in bridge-mode, a special loudspeaker cable adapter is required! Sentinel 3 only.**



Fig 19. Routing screen of Sentinel3 (with bridge-mode option)

# 7. Operation

## 7.7 Tab section: System

In this section, there are the system parameters that can be read or set, that are not required for “daily” operational usage. Through separate sub-tabs, operational data read-outs can be displayed and changed.

**7.7.1 Speaker** - this section shows the measured speaker (system) impedance, per channel; This read-out offers real-time load-verification, with which state of speaker function can be determined. Note: for an accurate reading, ample signal needs to be available (“the higher the signal, the higher the accuracy”). The measurement range is between 1,5 Ohms and 20 Ohms, above/below -- is indicated. (see fig.20)




Fig 20. Speaker impedance read-out




Fig 21. Amplifier status, temperature scales, fan speed level 1, AC mains 240V indication

**7.7.2 Amp** - this sections indicates the temperature of the power supplies (“SMPS” 2x) and amplifier stages (“amp” 4x) through a color scale from blue to red. (see fig.21)

The automatically selected AC power band is shown as “AC 120V” or “AC 240V”. The “power” indication shows the status of the smps1 and smps2 power supplies; If green, the smps is working properly; If the indication illuminates red, the smps is out of order. Then, the redundancy switching will maintain amp operation from only one smps, albeit at lower output levels.

# 7. Operation

---

## 7.7 Tab section: System




Fig 22. Set-up menu with setting options

**7.7.3 Setup** - in this section, different system functionalities can be set, like system lock, screensaver function (the “eye”), date/time and mute-setting options. (see fig.22)

**7.7.4 Lock system** - with pressing this button, the QWERTY keyboard pops-up, to enter a password code; Confirm code and the active tab switches to Overview tab, with which all tabs are locked and only the Mute buttons can be operated. (see fig.22)

**7.7.5 Lock preset** - with pressing this button, the QWERTY keyboard pops-up, to enter a password code; Confirm code and the active tab switches to Overview tab, with which System tab and the Preset tab are locked. (see fig.22)

To unlock, touch any locked tab and the QWERTY keyboard will pop-up, asking for password.

# 7. Operation

## 7.7 Tab section: System

**7.7.6 High headroom/low noise** - the analogue input sensitivity can be adjusted; “High headroom”, allows driving the amp with an analog input signal +21dBV (+23dBu) Use this setting when the signal source can exceed +6dBV (+8dBu), usually higher-SPL applications. In the “Low noise” setting the input stage is fully driven with a +6dBV (+8dBu) signal. The signal is internally boosted to fully utilize the ADC's quantization space, resulting in a better signal-to-noise ratio. Use this setting when working with signals not exceeding +6dBV (+8dBu), usually low-SPL applications. This applies to the analogue inputs only. In both settings the overall gain remains the same. (see fig.22)

**7.7.7 Mute preferences**- different muting options prevents unwanted passing of audio, while being active in the Preset tab, or with startup. (see fig.23)

**7.7.8 Backlight brightness** - this can be adjusted, in “manual” (with slider bar) or “automatic” (through light sensor behind the front panel); Both the brightness of the display and the Alcons logo are adjusted. (see fig.24)




Fig 23. Mute preferences set-up menu




Fig 24. Backlight control set-up menu

**7.7.9 Screen saver** - this function enables time-out setting for the screen saver (the “Eye”). Selectable settings are: Activation after 30 seconds, 2 minutes, 10 minutes or off. (see fig.22)

**7.7.10 Change date/time** - date and time can be adjusted, with which both the visible date/time dialog as well as the internal “date/time stamp” in the log files is changed. (see fig.22)

# 7. Operation

## 7.7 Tab section: System

**7.7.11 Oplog** - this “operation log” section shows the status of the different sections inside ALC. When the illuminated encoder indicates a certain color/status, the oplog shows the actual report on the system status. When selecting “oplog” the function status of the encoder is reset (red blinking to white).

**7.7.12 Clean oplog** - touching this button cleans the log files/messages on the display: It does NOT clean the internal logging of the Sentinel, as that (more extensive) data cannot be erased by the user.

**7.7.13 Copy log files** - touching this button copies the internal log files onto the selected drive; For this, a USB stick (min. 256Mb size) needs to be plugged into the front-located USB connector.



**The internal logging reports any setting and operating status of power supplies, amplifier stages, main controller, DSP and front control. It stores these data for a maximum of 100MB, which equals a period of 640 days of non-stop operation logging.**



Fig 25. Amplifier operation log report



Fig 26. Amplifier firmware information and update

**7.7.14 Firmware** - the different firmware/ library versions are shown here. Through the “update” keys (+ USB connector on the front) firmware updates can be loaded. (see fig.26) The procedures for updating are described in separate instruction/ release notes, which come with the distributed software. Read these instructions carefully before updating an ALC Sentinel amplifier. Ensure that the amplifier is never switched off during updating and that the mains power supply is stable. It is highly recommended that a firmware update is done at an appropriate moment. i.e. not “minutes” before a show.



# 7. Operation

## 7.7 Tab section: System

**7.7.15 Project** - the settings of all sections of the amplifier can be stored in a Project file / User preset. Up to 100 user presets can be stored internally; Each project can also be stored externally; For this, a USB stick needs to be plugged into the front-located USB connector. Through the QWERTY keyboard each project file can be renamed. A full 100-project user file takes up around 2MB. Recalling or loading a project can be done from internal or external (USB) storage. (see fig.27)




Fig 27. Project storage or recall



Fig 28. Network information



**Project files are transferable between ALC Sentinel amplifiers. For installed situations it is advised to save individual amplifier project files for backup purposes.**

**7.7.16 Network** – The shown MAC (media access control) address is a unique identifier on the ALC Sentinel network interface, used for communications on a physical network segment. Before the unit is accessible via the network it first needs an IP address. There are two ways of getting an IP address: automatically (via DHCP) or manual. If the DHCP is enabled the unit will get an IP address from the DHCP server in the network, if one is available. The other way is by manually entering the IP address via the "edit IP address" button. The "edit IP address" button will be activated when the DHCP is disabled. When an ALC Sentinel is connected to a network, the assigned IP address will be shown if DHCP is enabled, otherwise the previous assigned or manual entered IP is displayed.

The "maintenance" tab is intended for service purposes only. A "blink logo" tab is added for easy identifying the amplifier in a multiple rack assembly. (see fig.28)

# 7. Operation

---

## **7.8 Remote Control through a VNC client**

The ALC Sentinel is equipped with a VNC server to access the display screen remotely. This can be useful to operate a number of ALC Sentinel amplifiers connected to a wired LAN. To access the VNC server, a VNC client must be installed on the remote device, this can be a laptop, desktop PC, smartphone or tablet which can run VNC client software.

An example of a (free) Windows VNC client is TightVNC, the only thing it needs is the IP address of the ALC Sentinel before connecting. Apple devices and Linux distributions come standard with VNC client software. For android phone's and tablets, different client app software is available. Make sure it supports VNC as that is different from the "remote desktop" protocol. A nice simple and fast version is Remote VNC from Yongtao Wang. Most VNC clients allow you to optimize for speed. When response is slow, check if the bpp (color quality) can be set to a lower mode, i.e. 8bpp setting and that the screen resolution is set to auto or 480x272 pixels (ALC Sentinel standard display resolution).

With most VNC clients it is only necessary to set the IP address of the ALC Sentinel and press connect. The ALC Sentinel operates with a DHCP server to acquire an IP address from the router in the LAN. Beware, this can take up to 5 minutes. In the system->network tab, the IP address is displayed. This tab also features a "blink logo" button which can be used to identify units later on. Port 5900 is used by VNC and the ALC Sentinel. Most client software set this port as default, otherwise you can change this in the client software.

Devices with a keyboard and mouse can select all selection-boxes/buttons with the mouse and turn up/down parameters with the up/down key and page-up/page-down key for fast changes. The EQ/Delay boxes need to be confirmed to have effect to do this press the enter button to confirm. The advantage of a desktop/laptop is that multiple units can be connected to at the same time.

# 7. Operation

## 7.8.1 Remote Control with the Virtual Encoder™



Fig 29. Virtual encoder

For touch screen devices, the ALC Sentinel display features a transparent button to activate a Virtual Encoder™. This allows you to change certain parameters that need the encoder motion. To activate this Virtual Encoder™, press the area next to the System tab(see arrow), this will then pop up the Virtual Encoder™. (see fig.29)

To change for example the Q in the “Eq” tab section:

press the Q selection box (the box outline turns green when selected)

press the area next to the system button to let the Virtual Encoder™ pop up. turn the dial to get the desired Q, the dial starts blinking to indicate a parameter change.

press the enter on/ off button to confirm. The Virtual Encoder™ has the color schemes of the actual encoder.

This Virtual Encoder™ can also be used to get the ALC Sentinel in or out of standby mode and panic mute.

## 8. Safety

---

### Protection circuits

#### Guidance

This is the limiting of the amplifier output for the protection of the speaker (this can be excursion or RMS limiting); Thus works different for each speaker/preset. The scale runs from top to bottom; When yellow bar reaches the bottom, maximum compression/limiting is reached. It is not a problem when the gain reduction is activated, but the LF response and overall dynamics will be limited.

#### Temperature protection

The ALC Sentinel is cooled by two 80mm variable speed fans located behind at the back of the amplifier. Fan speed increases only as required by measured temperatures, keeping fan noise to a minimum. Under extreme thermal load the fans will force a very large volume of air through the heat sinks. If one of the SMPS power supplies or Amp stages surpasses the maximum allowed temperature, the ALC Sentinel temperature protection circuits become active and will shut down particular components.

To indicate this, the rotary encoder is flashing and a message will appear on the oplog screen.

#### SMPS power supply protections

The power supplies will check the overvoltage/ under voltage during start up.

Also a current limiter will be become active during operation. The amplifier will shut down during a possible Mains dip.

#### Amp module protections

There are several error protection circuits on each module.

The speaker outputs have short circuit protection. Also the SIS circuit are protected on faulty +/- wiring and short circuit.

## 9. Service and support

---

### Warranty

#### Summary

Alcons Audio BV warrants the original purchaser and any subsequent owner of each new Alcons product, for a period of three years from the date of the original purchase by the original purchaser that the new Alcons product is free of defects in materials and workmanship. Alcons Audio BV warrants the new Alcons product regardless of the reason for failure, except as excluded in this warranty. In order to obtain warranty, you must keep the original sales receipt to establish the exact date of purchase.

#### Items excluded from warranty

Warranty does not cover any product which has been damaged because of any misuse, accident, or negligence. Warranty also does not extend to a new Alcons product if the serial number has been defaced, altered or removed.

#### What we will do

Alcons Audio BV will replace defective parts and repair malfunctioning products, regardless of the reason for failure (except as excluded). Warranty work can only be performed at our authorized service centres, or at our factory.

#### Disclaimer

Alcons Audio BV is not liable for any damage to loudspeakers, amplifiers, or any other equipment that is caused by negligence, misuse or improper installation of the ALC Sentinel amplifiers. Alcons Audio BV is not liable for any incidental damages resulting from any defect in the new Alcons product. This includes any damage to another product or products resulting from such a defect.

Alcons Audio BV reserves the right to change specifications without notice.



# 9. Service and support

## Error log list

When the illuminated encoder indicates a certain color/status, the olog shows the actual report on the system status.

<b>Component</b>	<b>Error type (oplog)</b>	<b>Result</b>	<b>Action by user</b>
Amp module	Over voltage on V+	Amp module off, 1 second cycle	None, unless it starts preventing normal operation then repair is required
	Over voltage on V-	Amp module off, 1 second cycle	None, unless it starts preventing normal operation then repair is required
	Under voltage on V+	Amp module off, 1 second cycle	None, unless it starts preventing normal operation then repair is required
	Under voltage on V-	Amp module off, 1 second cycle	None, unless it starts preventing normal operation then repair is required
	Overload Error	Amp module off, 1 second cycle	Amp output shorted? check cables
	Switching frequency	Amp module off, 1 second cycle	None, unless it starts preventing normal operation then repair is required
	Amplifier Fail	Emergency stand-by mode	Repair is required.(remove Amp power cable)
	DC error	Amp module off, 1 second Cycle	Check inputs, otherwise repair is required
	Over voltage on VDR	Amp module off, 1 second cycle	None, unless it starts preventing normal operation then repair is required
	Under voltage on VDR	Amp module off, 1 second cycle	None, unless it starts preventing normal operation then repair is required
Power supply	AmplifierReady	N/A	
	Over temperature	Amp module off	Should be prevented by limiter
	Signal Integrity Sense (SIS) error	Amp module off	Cable error (wire short, crossed sense wires) or amp hardware failure
	SMPS has been disabled but no fault detected	None, purely status readout	
	SMPS Fail pin was set but the SMPS hasn't been enabled	None, purely status readout	
Fans	SMPS is disabled and the fault was detected	None, purely status readout	SMPS hw defect or mains power dip, in this case amp will recover
	Fan error 1; fan error 2	A fan stopped, amplifier in safe mode, with both belonging amp modules switched off. The remaining fan (I.e fan 1) increases speed for proper cooling of amp ch 1+2 or amp ch. 3+4 (fan 2). When both fans fail,the amp goes into emergency standby mode	clear the fan obstruction or return to service centre if fan won t start anymore
Mains Voltage	Mains voltage out of window	System off	Check mains voltage, this amp needs at least a 16A outlet
	No mains voltage or voltage below minimum	System off	Make sure the mains Voltage is stable, especially on generators
	Mains voltage above absolute maximum	System off	Make sure the mains Voltage is stable, especially on generators
I2C bus	Start-up fault	System does not start	This can happen when main Voltage is too low
	Communication error	No readout on the amplifier module, could mean no functional protections	Try restart. Return unit if problem keeps existing
Temperature	Bus locked up	No communication between front and peripherals	Needs PowerCon switch on/ off
	Temperature error	Emergency stand-by	Improve system air flow
AC	Front_AC_Reset	DSP reset	None, Amp restarts automatically after mains dip
	Front_Err_ACFail	100ms no sound	None, Amp restarts automatically after mains dip



## 9. Service and support

---

### Contact information

#### Mailing address:

Alcons Audio BV  
De Corantijn 69  
1689 AN ZWAAG  
The Netherlands

Tel.: +31 (0)229 283090  
Fax.: +31 (0)229 283099

#### World Wide Web:

<http://www.alconsaudio.com>

#### E-mail:

[info@alconsaudio.com](mailto:info@alconsaudio.com)



# 10. Specifications

---

## ALC Sentinel 3

Input sensitivity for max RMS power	@ 4 Ω	1.22 Vrms / +3.9 dBu
Maximum input level		+24 dBu
Input impedance		44 kOhm balanced
Input CMRR	@ 1 kHz	67 dB
Frequency response	all loads	0 Hz – 50 kHz +0 /-3 dB
Gain		32 dB / 40x
Channel separation		100 dB
THD+N, IMD	@ 20 Hz – 20 kHz, 350W, 4 Ω	<0.004 %
S/N ratio	analog input	>112 dB A-wght
S/N ratio	digital input	>118 dB A-wght
Noise floor		typical 7uV, max 8uV (unweighted)
Damping factor	@ 1 kHz, 8 Ω	>10.000:1
Stereo power	@ 8 Ω RMS 1% THD	380 W
	@ 4 Ω RMS 1% THD	750 W
	@ 2 Ω RMS 1% THD	980 W
Bridged mono power	@ 8 Ω RMS 1% THD	1400 W
	@ 4 Ω RMS 1% THD	1820 W
Mains supply voltage		90 - 132 VAC; 180 – 264 VAC @ 50-60 Hz automatically selected
Current draw	idle	70 VA
	@ 1/8 of full power into 4 Ω	790 VA
Latency		2.9 ms
Operating condition		-10°C ...+40°C / +14°F...+104°F
Weight		8,8 kg/ 19,4 lb
Housing		19 inch rack mount, 2 HE, 408 mm / 16 inch deep behind the mounting surface
Dimensions (hxwxh)		88x484x440mm/3.5"x19"x17¼"



# 10. Specifications


---

## ALC Sentinel 10


Input sensitivity for max RMS power	@ 4 $\Omega$	2.12 Vrms / +8.7 dBu
Maximum input level		+24 dBu
Input impedance		44 kOhm balanced
Input CMRR	@ 1 kHz	67 dB
Frequency response	all loads	10 Hz – 60 kHz +0dB, -3dB
Gain		32 dB / 40x
Channel separation		100 dB
THD+N, IMD	@ 20 Hz -20 kHz, 1000 W, 4 $\Omega$	<0.005 %
S/N ratio	analog input	>112 dB A-wght
S/N ratio	digital input	>118 dB A-wght
Noise floor		typical 18uV, max 20uV (unweighted)
Damping factor	@ 1 kHz, 8 $\Omega$	>10.000:1
Stereo power	@ 8 $\Omega$ RMS 1% THD	1450 W
	@ 4 $\Omega$ RMS 1% THD	2500 W
	@ 2 $\Omega$ RMS 1% THD	2450 W
Mains supply voltage		90 - 132 VAC; 180 – 264 VAC @ 50-60 Hz automatically selected
Current draw	idle	240 VA
	@ 1/8 of full power into 4 $\Omega$	2060 VA
Latency		2.9 ms
Operating condition		-10°C ...+40°C / +14°F...+104°F
Weight		11.6 kg / 25.5 lb
Housing		19 inch rack mount, 2 HE, 448 mm / 17.6 inch deep behind the mounting surface
Dimensions (hwxwd)		88x484x480mm/3.5"x19"x18.9"



# 11. Block diagram



# 11. Block diagram Bridge mode



## 11. EC declaration of conformity

---

Alcons Audio BV  
De Corantijn 69  
1689 AN ZWAAG  
The Netherlands

States that the following products:

ALC Sentinel 3  
ALC Sentinel 10


Are in conformity with the provisions of:

Low Voltage Directive, 2006/95/EC  
Electro-Magnetic Compatibility Directive, 2004/108/EC

Applied rules and standards:

EN60065 (Electrical Safety)  
EN55103-1 (Emission)  
EN55103-2 (Immunity)

Established at Zwaag, the Netherlands,  
July 1st, 2014



T.H. Back  
Managing Director



# Notes

---

