FLYBF181 Quick Rigging Instruction

This system is designed for permanent indoor installations

Overview:

1 BF181 Loudspeaker
2 FLYBF181 U-bracket
3 FLYBF181 Connection frame
4 GRDBF181 – **WLL 300kg** / 6x BF181
5 Connection screw M8x12 Torx 40 strength class 8.8
A 1.5T shackle - 2 point (center) rigging
B 1T shackle - 4 point (corner)rigging

Assembly:

Place 2 U-brackets (2) under the first BF181 on each end of the sliding strips. Connect a connection frame (3) on both sides of the U-bracket.

Use medium strength thread locking fluid

Do not fully tighten the M8x12 screws. Place the GRDBF181 (4) on top of the BF181. Connect both U-brackets to the GRDBF181 with the M8x12 screws. Raise the first piece of the array. Tighten all screws firmly. There are holes in the bottom of each U-bracket for using wood screws as an extra optional connection.

Place the next BF181 under the array and place the next two U-brackets (2). Attach the connection frames(3). Lower the array until the connection between the U-brackets can be made.

Continue this procedure with the rest of the cabinets.

When the array is completed, check all screw connections.

